

SILTEC

TOOCLEAN WIPE

THE PROFESSIONAL RANGE

TOOCLEAN is a rinsing-and-water free multi-purpose cleaning wipe for a one-time or recurrent maintenance of your car, motorcycle, scooter, go-karting, quad ...

TOOCLEAN formulation which is contained in a single wipe can take care, clean and give back the bright new brilliance of the bodywork, wheels, paint, plastic interiors, exteriors, fairings, front fairings, windows, windshields, headlights, chrome, the leatherette upholstery and leather of a vehicle in a single operation.

TOOCLEAN

- Cleans, polishes, protects, stops the impact of time on all surfaces without the risk of scratching or damaging the paint and alter the plastic.
- Cleans and polishes of surfaces without water, foam or rinsing.
- Removes impacts and insect traces on the bodywork, fairing, front fairings, windscreens, headlights and plastics.
- Scrubs, removes the tar, cleans, rims without altering light alloys, varnishes, plastics and paints.
- Protects the bodywork by leaving an invisible anti-fouling film.
- Without any liquid polluting emissions (the dirt is trapped in the wipe).
- Anti-rain and anti-fouling deposits.
- Anti-tar, anti-bitumen deposits.
- TOOCLEAN delays fouling.

DIRECTIONS FOR USE

Take a wipe out of the box. Double it up and lay it flat on the hand. Move it onto the surface without pressing. When the surface becomes «slippery» you can slightly increase the pressure. Always proceed by small surfaces, without rubbing, describing circle movements. TOOCLEAN traps the particles, while cleaning and applying a film on the surface. Polish with the microfiber cloth provided, making a quick circular motion when wiping without pressing too much. Start your cleaning with the least dirty surfaces and finish with heavily soiled areas.

H319 Causes serious eye irritation.

P101 If medical advice is needed, have product container or label at hand.

P102 Keep out of reach of children.

P103 Read label before use.

P264 Wash thoroughly after handling.

P280 Wear eye protection / face protection.

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P337+P313 If eye irritation persists: Get medical advice/attention.

PACKAGING

80 wipes per bucket

6 buckets per box



www.siltec-actalys.com

ACTALYS - ZA DU HAUT DES TAPPES - BP 70065 - 54310 HOMECOURT - FRANCE
TEL +33 3 82 20 67 50 - FAX +33 9 70 61 29 66 - SILTEC-ACTALYS@ORANGE.FR